



Sony MHC-V73D High Power Bluetooth® Party Speaker with omnidirectional party sound and light

Model: MHCV73D.CEL

Manufacturer: SONY

EAN: 4548736107915

Product Code: 1010549

R21,000

Create the ultimate dancefloor experience

Feel the beat of your favourite tracks in every corner of your venue with Omnidirectional Party Sound, then watch as your dancefloor comes to life with the Omnidirectional Party Light and Speaker Light.

Bring stunning sound to the party

Dance and sing along to your favourite tracks wherever you are in your venue. With High-efficiency Tweeters, High-efficiency Midrange and angled Midrange Drivers, your parties will be booming with

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices

may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or

typographical errors. We recommend checking the current information before purchasing.

shop.cssi.co.za | sales@cssi.co.za | +27 (11)541-9950

powerful, vibrant sound to please every partygoer.

Bigger sound with Omnidirectional Party Sound for the best parties ever

Bring the party to everyone, no matter where they are at your venue. With Omnidirectional Party Sound, created by High-efficiency Tweeters and High-efficiency Midrange, your music will reach everyone at your party, whether they are standing or sitting, singing or dancing.

Four High-efficiency Tweeters will completely fill your venue

The four upward-facing High-efficiency Tweeters that uses horn tweeters, two on the front and two on the back of the unit, expand the sound stage and increase sound pressure level upward, spreading the sound around whatever venue you choose.

High-efficiency Midrange for better vocals

High-efficiency Midrange that uses mid horn speakers on the front and back distributes sound with improved clarity and sound pressure for the vital midrange frequencies. This means that whether you're in front of the unit or behind it, close up or far away, you can enjoy clearer vocals as you dance or sing along to your favourite tracks.

Feel the beat at long distances with JET BASS BOOSTER

A tapered bass reflex duct structure concentrates the airflow of the bass sound, so you can hear it clearly and feel it physically, wherever you are in the crowd and over long distances.

Hear it like it's live

DSP Technology creates a festival vibe, giving your music the realistic ambience of a live concert.

Restores detail to digital music

The Digital Sound Enhancement Engine (DSEE) restores detail to compressed music files, producing high-quality sound that's closer to the original CD recording.

Create an unforgettable atmosphere

Light up the party from floor to ceiling with the Omnidirectional Party Light and Speaker Light. Send out waves of deep blue, sky blue, and green, with a multicoloured stripe, so you can enjoy an authentic nightclub or outdoor festival atmosphere.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.

shop.cssi.co.za | sales@cssi.co.za | +27 (11)541-9950

Experience Omnidirectional Party Light

Watch the video to see Omnidirectional Party Light in action.

Unleash your inner pop star

Keep everyone entertained – with two microphone inputs, you and your guests can go head-to-head singing along to your favourite tunes. Alternatively, add a rock and roll layer by connecting a guitar to one of the inputs and using the system as a guitar amp. Enjoy three modes: Clean for a clear sound, Overdrive for a distorted guitar sound, and Bass for your bass guitar. And when you're finished, the unit has two microphone holders, so you can store your mics safely.

Vertical and horizontal Gesture Control

Skip a track, change up from flanger to WAH, turn up the karaoke mic, control the pitch of the mic and music, or turn up the volume with a vertical or horizontal wave of your hand. Gesture Control lets you control the functions of the MHC-V73D quickly and easily, so you can stay right in the heart of the party moment.

Play along to the beat with TAIKO Mode

Add your own drumming into the mix with TAIKO Mode, and put your rhythm to the test when you play against friends in TAIKO Game Mode.

TAIKO Mode

You can play along on samplers including bongo, djembe, surdo and the Japanese Taiko drum, just by tapping the top panel in time to the beat.

Put the party in your hands with Fiestable

Entertaining, intuitive and easy to use, the Fiestable app is a fun feature control that hands you over complete control of the MHC-V73D. To use the Fiestable app, you'll need to download the Sony | Music Center app first. Then, take control of the music, lighting and more, all by simply tapping your phone or using your voice.

Let your friends create the Party Playlist via Fiestable

Everyone can add their favourite tunes to your playlist with the Fiestable app. Let your guests add music stored in their smartphones over your Wi-Fi network, so your party never needs to stop.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.

shop.cssi.co.za | sales@cssi.co.za | +27 (11)541-9950

Find your singing superstar with Karaoke Ranking via Fiestable

Compete to find the King or Queen of karaoke at your party with Karaoke Ranking. And if anyone ranks in the Top 10, they can record their name and song title in the leader board.

Be the Party King

Share your party status on social media with just one click from the Fiestable app. Then, turn up the music and climb the party people ranks to become the certified Party King.

Run everything from the dancefloor

The Sony | Music Center app lets you control music and sound settings right from your phone. Plus, the Fiestable app puts you in charge of the light colours and lets you activate DJ and KARAOKE Modes. Make changes with a flick of your wrist, thanks to intuitive motion control.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.

shop.cssi.co.za | sales@cssi.co.za | +27 (11)541-9950