



CHERRY DW 9100 SLIM SWITZERLAND -



Model: JD-9100CH-1

Manufacturer: CHERRY

EAN: 4025112095283

Product Code: 1057907

R3,189

The CHERRY DW 9100 SLIM set features rechargeable lithium batteries that last for weeks of work. You can then conveniently charge the wireless mouse and keyboard using the USB-C cable included, even while you are working. To ensure that the rechargeable batteries are still charged after a holiday, the wireless keyboard and mouse can be switched off completely with a switch.

Rechargeable designer desktop with many extra features

The CHERRY DW 9100 SLIM combines innovative functions, outstanding workmanship and a very slim design. The mix of aesthetics and optimum comfort is perfect for any modern work desk.

Wireless RF or Bluetooth transmission - the choice is yours.

Why choose one or the other when you can have both? A switch on the keyboard and mouse lets you toggle instantly between Bluetooth and 2.4 GHz connectivity. The USB receiver for 2.4 GHz wireless transmission is included in the bundle. In both cases, data is transferred with AES-128 encryption over a range of up to 10 meters.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.

shop.cssi.co.za | sales@cssi.co.za | +27 (11)541-9950

The charging concept - carry on working while you charge.

The rechargeable lithium batteries power the keyboard and mouse for weeks on a single charge. Even when the status LEDs indicate low batteries, you can keep on working in comfort while simply charging the cordless desktop set with the USB-C charging cable supplied. To make the battery last even longer, the set has an ON/OFF switch.

The keyboard - stable and flexible at the same time.

Excellent design and high quality go hand-in-hand with the CHERRY DW 9100 SLIM. A metal plate provides maximum strength and stability while the keyboard remains flat. In terms of flexibility, it leaves nothing to be desired. The separate, magnetic support bar can be fitted in seconds to provide a steeper typing angle. When not in use, it can be removed just as quickly.

Maximum comfort - everything a keyboard needs.

The basis for the excellent typing feel of the CHERRY DW 9100 is the high-quality SX scissor mechanism. The defined and precise pressure point is similar to a laptop keyboard and is key to productivity at work. The three status LEDs integrated in the keys are also very useful. There's no need to look whether the shift key, scroll key or Num-Lock keys are activated. These keys also flash to warn that the battery is getting low. The additional keys on the cordless keyboard have been chosen with practicality in mind. The desktop set only has the most important and frequently used keys: "Windows lock", "Open browser", "Volume Down", "Volume Up", "Mute" and "Open calculator". This keeps the cordless keyboard tidy and is very user-friendly.

The mouse - design meets comfort.

With its numerous features and rubberised sides, the cordless mouse is a worthy partner for the keyboard. The compact shape creates an ideal form for the hand that feels instantly familiar. A DPI switch lets you switch between three levels at the touch of a button: 600, 1000 or 2400 dpi. A two-color status LED provides information on the battery status, the charging status, the selected resolution or the connection status at any time. The cordless mouse, which can handle any mobile use, comes with a metal mouse wheel. It continues to scroll effortlessly throughout the day. Even the USB receiver has its own place in the mouse. A magnet keeps it secure and is always ready for use.