CSSi SA - "Securing Tomorrow, Today"
Waterfall Office Park, 28 Augrabies Rd Vorna Valley, Midrand, 1685
Generated: 2026-10-30 17:41

Verbatim 32135 GPS tracker/finder Personal Black, Pink, White

Model: 32135

Manufacturer: VERBATIM

EAN: 023942321354

Product Code: 1209431

R1,292

Track your essentials with Verbatim's My Finder Bluetooth Tracker

Verbatim’s My Finder is a tracking device that works exclusively with Apple’s Find My App. Simply attach the My Finder to any item that you need to keep track of and you can locate the item through the Find My App on your iPhone, iPad and MacBook.

Misplaced keys, bags and other valuables are a thing of the past with Verbatim’s My Finder Bluetooth tracker. Simply attach the versatile tag to the item you want to track and use Apple Find My app to locate it when missing.

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
shop.cssi.co.za | sales@cssi.co.za | +27 (11)541-9950

Within the app’s Lost Mode, you can enter your contact details in the event that your missing item is located by someone else in the Apple Find My network.

Locate by sound or map

Utilising the Apple Find My ecosystem, you can easily track your item’s location. If you are in close range, select “Play Sound” in the app and follow the beep to find your lost item. Alternatively, select your missing item in the app and locate it on a map. The whole process is anonymous and encrypted to protect your privacy.

Long battery life

Equipped with a Lithium battery, enjoy over 12 months battery life- no need for frequent battery changes. With IP66 protection the My Finder is water-resistant and dustproof for durability.

Smart Notifications

With smart notifications enabled by default, you’ll receive an alert on your phone when your My Finder is out of your Bluetooth range. Attach it to your laptop bag or backpack, or slip it into your wallet so you don’t walk out the door without them.

Never lose your keys, backpack or luggage again!

The product information provided is for reference purposes only. Technical specifications, photos, descriptions and prices may change without prior notice. The manufacturer and seller are not responsible for possible data discrepancies or typographical errors. We recommend checking the current information before purchasing.
shop.cssi.co.za | sales@cssi.co.za | +27 (11)541-9950